

# strands<sup>®</sup>

-lighting division

## MANUAL

### CRUISE LIGHT STROBE CONTROLLER

#### INCOMING CABLES

**RED** - Positive (+)

**BLACK** - Ground (-)

**YELLOW** - Pattern selection

**BLUE** - Steady on (Connect to +VDC)

#### OUTGOING CABLES

##### 6 CHANNELS

**RED** - Positive (+) (Maximum 30W/channel)

**BLACK** - Ground (-) (not needed if light is connected to ground)

#### PATTERNS

1. All single flash
2. All double flash
3. All quad flash
4. Channel 1, 3, 5 alternating with 2, 4, 6
5. 1, 3, 5 / 2, 4, 6 alternating double flash
6. 1, 3, 5 / 2, 4, 6 alternating quad flash
7. 1 >>> 6, single (1channel lit at a time)
8. 6 >>> 1, single (1channel lit at a time)
9. 1 >>> 6, double (2channels lit at a time)
10. 6 >>> 1, double (2channels lit at a time)
11. All patterns random, ~13seconds on every pattern
12. Steady on

#### READ THIS BEFORE INSTALLATION

READ ALL INSTRUCTIONS AND STUDY DIAGRAMS BEFORE INSTALLATION!

#### LEGAL MOUNTING

Check with state or local authorities for laws governing usage and proper mounting of your new product.

#### TAKE CARE OF YOUR PRODUCT

Keep the product clean. Dirt may shorten the products lifetime.

#### WARNING!

Do not use higher volts than the product description states.

Do not overload channels with lights consuming more wattage than each channel is intended for.

